COLT NEW SERVICE MODEL SCHEMATIC



Note: The "Schematics" provided on this site are to be used as a general reference to assist you in identifying parts and may not be an illustration of your <u>EXACT</u> model.

KEY

1	Hammer
2	Hammer Pin
3	Hammer Stirrup
4	Hammer Stirrup Pin
5	Strut
6	Strut Spring
7	Strut Pin
8	Firing Pin
9	Firing Pin Rivet
10	Safety
11	Safety-Lever
12	Hand
13	Trigger
14	Trigger Pin
15	Mainspring
16	Bolt
17	Bolt Spring
18	Bolt Screw
19	Rebound Lever
20	Rebound Lever Pin
21	Crane Lock Detent
22	Crane Lock Spring
23	Crane Lock Screw
24	Sideplate
25	Sideplate Screw
26	Latch
27	Latch Spring
28	Latch Spring Guide
29	Latch Pin
30	Cylinder
31	Ratchet
32	Ejector Rod
33	Ejector Rod Head
34	Ejector Spring
35	Crane Bushing
36	Crane
37	Barrel
38	Stock Pin
39	Stock Screw
40	Stock Screw
41	Stock Screw
42	Stock Screw Nut
43	Recoil Plate
44	Frame

Parts Not Shown

Cylinder Bushing
Cylinder Bushing Pin